

## Quick Start Guide for configuring Linux that is preinstalled on an IBM Power Systems LC server.

*This guide describes a quick and easy way to configure an IBM Power Systems LC server that is preinstalled with Linux.*

### Overview

Use this information to configure Linux on an IBM Power System LC server.

### 1 Step 1: Completing the prerequisites and booting your firmware



Before you power on the system, ensure that you have the following items:

- Ethernet cable
- VGA monitor. The VGA resolution must be set to 1024x768-60Hz.
- USB Keyboard
- Power cords and outlet for your system.

Complete these steps:

- If your system belongs in a rack, install your system into that rack. For instructions, see IBM Power Systems information at <https://www.ibm.com/support/knowledgecenter/>.
- Connect an Ethernet cable to the embedded Ethernet port next to the serial port on the back of your system. Connect the other end to your network.
- Connect your VGA monitor to the VGA port on back of system.
- Connect your USB keyboard to an available USB port
- Connect the power cords to the system and plug them into the outlets.

At this point, your firmware is booting. Wait for the green LED on the power button to start flashing, indicating that it is ready to use. If your system does not have a green LED indicator light, then wait 1 to 2 minutes.

## 2 Step 2: Configuring the IP address

To set up or enable your network connection to the BMC firmware, use the Petitboot bootloader interface. Follow these steps:

- a. Power on your server using the power button on the front of your system. Your system will power on to the Petitboot bootloader menu. This process takes about 1 - 2 minutes to complete. Do not walk away from your system! When Petitboot loads, your monitor will become active and you will need to push any key in order to interrupt the boot process.
- b. At the Petitboot bootloader main menu, select Exit to Shell.
- c. Run `ipmitool lan print 1`. If this command returns an IP address, verify that is correct and continue. To set a static IP address, follow these steps:
  - i. Set the mode to static by running this command: `ipmitool lan set 1 ipsrc static`
  - ii. Set your IP address by running this command: `ipmitool lan set 1 ipaddr ip_address` where *ip\_address* is the static IP address that you are assigning to this system.
  - iii. Set your netmask by running this command: `ipmitool lan set 1 netmask netmask_address` where *netmask\_address* is the netmask for the system.
  - iv. Set your gateway server by running this command: `ipmitool lan set 1 defgw ipaddr gateway_server` where *gateway\_server* is the gateway for this system.
  - v. Confirm the IP address by running the command `ipmitool lan print 1` again.

**Note:** This network interface is not active until after you perform the following steps.

- d. To reset your firmware, run the following command: `ipmitool mc reset cold`.

This command must complete before continuing the process; however, it does not return any information. To verify that this command has completed, ping your system BMC address (the same IP address used in your IPMItool command). When the ping returns successfully, continue to the next step.

**Note:** If your ping does not return successfully within a reasonable amount of time (2 - 3 minutes), try these additional steps:

- i. Power your system off with this command: `ipmitool power off`.
- ii. Unplug the power cords from the back of the system. Wait 30 seconds and then apply power to boot BMC.

### 3 Step 3: Powering on your server with IPMI

Intelligent Platform Management Interface (IPMI) is the default console to use when connecting to the OPAL firmware.

Use the default values for IPMI:

- Default user: ADMIN
- Default password: admin

**Note:** After your system powers on, the Petitboot interface loads. If you do not interrupt the boot process by pressing any key within 10 seconds, Petitboot automatically boots the first option.

To power on your server from a PC or notebook that is running Linux, follow these steps:

- a. Open a terminal program on your PC or notebook.
- b. To power on your server, run the following command:

```
ipmitool -I lanplus -H server_ip_address -P ipmi_password chassis power on
```

where *server\_ip\_address* is the IP address of the Power system and *ipmi\_password* is the password set up for IPMI.

**Note:** If your system is already powered on, continue to active your IPMI console.

- c. Activate your IPMI console by running this command:

```
ipmitool -I lanplus -H server_ip_address -P ipmi_password sol activate
```

**Note:** Use your keyboard up arrow to display the previous ipmitool command. You can edit previous commands to avoid typing the entire command again. If you need to power off or reboot your system, deactivate the console by running this command:

```
ipmitool -I lanplus -H server_ip_address -P ipmi_password sol deactivate
```

To reboot the system, run this command:

```
ipmitool -I lanplus -H server_ip_address -P ipmi_password chassis power reset
```

### 4 Step 4: Booting Linux



To boot your Linux distribution, select it in the Petitboot bootloader menu and press Enter.

Preinstalled IBM Power systems have default users and passwords set up. This information is included with your system paperwork. In general, the default user names and passwords are as follows:

**On a system preinstalled with Ubuntu:**

Default user: ibm  
Default user: passw0rd

**On a system preinstalled with other distributions:**

Default user: root  
Default user: PASSWORD

**Note:** Ubuntu 14.04.3 and Red Hat Enterprise Linux 7.2 LE may not contain the latest version of IPMItool. To install the latest version on an Ubuntu system, run the following commands:

```
apt-get update  
apt-get install ipmitool
```

To upgrade IPMItool on a Red Hat Enterprise Linux system, use IBM Linux on Power tools repository to download and install the latest version.

## 5 Step 5: Determine your level of IPMItool



In order to connect to the Power server, you must be using IPMItool level 1.8.15 or greater on the PC or laptop that you are using to connect to the Power system.

To determine your current level of IPMItool, run the following command: `ipmitool -V`. If this command returns a version earlier than 1.8.15, update your IPMItool version. Follow these steps:

- a. Download the IPMItool file: `wget http://sourceforge.net/projects/ipmitool/files/latest/download/ipmitool-1.8.15.tar.bz2 .`
- b. Unzip it by running these commands:

```
bzip2 -d ipmitool-1.8.15.tar.bz2
tar xvf ipmitool-1.8.15.tar
```

- c. Configure it by running these commands:

```
cd ipmitool-1.8.15
./configure
```

- d. Build it by running this command: `make`
- e. Install it by running this command: `sudo make install`
- f. Validate the installation by checking the version again: `ipmitool -V`

## More information



For more information, see the following resources:

- IBM Knowledge center at <https://www-01.ibm.com/support/knowledgecenter/>
- The Linux on Power® developer portal at [Linux on Power developer portal](#).