

## Supported Product list for Global Total Microcode Support Service

Nov-23

OCL: On-Site Code Load

RCL: Remote Code Load

| MTM      | Product Description                                       | Model Sub Category | Model Sub Group | US  | RCL | OCL |
|----------|---|--------------------|-----------------|-----|-----|-----|
| 1746-C2A | IBM System Storage DS3512 Express                         | System             | Midrange Disk   | Yes | No  | Yes |
| 2072-12F | IBM Storwize V5000E LFF Expansion Enclosure               | Expansion Unit     | Midrange Disk   | Yes | No  | Yes |
| 2072-12G | IBM FlashSystem 5000 LFF Expansion Enclosure              | System             | Midrange Disk   | Yes | No  | Yes |
| 2072-212 | IBM Storwize V5010E LFF Control Enclosure                 | System             | Midrange Disk   | Yes | Yes | Yes |
| 2072-224 | IBM Storwize V5010E SFF Control Enclosure                 | System             | Midrange Disk   | Yes | Yes | Yes |
| 2072-24C | V3700 SFF Dual Control                                    | System             | Midrange Disk   | Yes | No  | Yes |
| 2072-24F | IBM Storwize V5000E SFF Expansion Enclosure               | Expansion Unit     | Midrange Disk   | Yes | No  | Yes |
| 2072-24G | IBM FlashSystem 5000 SFF Expansion Enclosure              | System             | Midrange Disk   | Yes | No  | Yes |
| 2072-2H2 | IBM FlashSystem 5010 LFF Control Enclosure                | System             | Midrange Disk   | Yes | Yes | Yes |
| 2072-2H4 | IBM FlashSystem 5010 SFF Control Enclosure                | System             | Midrange Disk   | Yes | Yes | Yes |
| 2072-2N2 | IBM FlashSystem 5015 LFF Control Enclosure                | System             | Midrange Disk   | Yes | Yes | Yes |
| 2072-2N4 | IBM FlashSystem 5015 SFF Control Enclosure                | System             | Midrange Disk   | Yes | Yes | Yes |
| 2072-312 | IBM Storwize V5030E LFF Control Enclosure                 | System             | Midrange Disk   | Yes | Yes | Yes |
| 2072-324 | IBM Storwize V5030E SFF Control Enclosure                 | System             | Midrange Disk   | Yes | Yes | Yes |
| 2072-3H2 | IBM FlashSystem 5030 LFF Control Enclosure                | System             | Midrange Disk   | Yes | Yes | Yes |
| 2072-3H4 | IBM FlashSystem 5030 SFF Control Enclosure                | System             | Midrange Disk   | Yes | Yes | Yes |
| 2072-3N2 | IBM FlashSystem 5035 LFF Control Enclosure                | System             | Midrange Disk   | Yes | Yes | Yes |
| 2072-3N4 | IBM FlashSystem 5035 SFF Control Enclosure                | System             | Midrange Disk   | Yes | Yes | Yes |
| 2072-92F | IBM Storwize V5000E High Density LFF Expansion Enclosure  | Expansion Unit     | Midrange Disk   | Yes | No  | Yes |
| 2072-92G | IBM FlashSystem 5000 High Density LFF Expansion Enclosure | System             | Midrange Disk   | Yes | No  | Yes |
| 2072-F12 | IBM FlashSystem 5000 LFF Expansion Enclosure              | System             | Midrange Disk   | Yes | No  | Yes |
| 2072-F24 | IBM FlashSystem 5000 SFF Expansion Enclosure              | System             | Midrange Disk   | Yes | No  | Yes |
| 2072-F92 | IBM FlashSystem 5000 High Density LFF Expansion Enclosure | System             | Midrange Disk   | Yes | No  | Yes |
| 2072-U12 | IBM FlashSystem 5010 LFF Control Enclosure                | System             | Midrange Disk   | Yes | Yes | Yes |
| 2072-U24 | IBM FlashSystem 5010 SFF Control Enclosure                | System             | Midrange Disk   | Yes | Yes | Yes |
| 2072-V12 | IBM FlashSystem 5030 LFF Control Enclosure                | System             | Midrange Disk   | Yes | Yes | Yes |
| 2072-V24 | IBM FlashSystem 5030 SFF Control Enclosure                | System             | Midrange Disk   | Yes | Yes | Yes |
| 2076-12F | V7000 LFF Expansion                                       | System             | Other Storage   | Yes | No  | Yes |
| 2076-12G | IBM FlashSystem 7000 LFF Expansion Enclosure              | System             | Other Storage   | Yes | No  | Yes |
| 2076-24F | V7000 SFF Expansion                                       | System             | Other Storage   | Yes | No  | Yes |
| 2076-24G | IBM FlashSystem 7000 SFF Expansion Enclosure              | System             | Other Storage   | Yes | No  | Yes |
| 2076-624 | V7000 SFF Control   | System             | Other Storage   | Yes | Yes | Yes |
| 2076-724 | IBM Storwize V7000 NVMe Control Enclosure                 | System             | Other Storage   | Yes | Yes | Yes |
| 2076-824 | IBM FlashSystem 7200 NVMe Control Enclosure               | System             | Other Storage   | Yes | Yes | Yes |
| 2076-92F | V7000 HD LFF Expansion                                    | Expansion Unit     | Other Storage   | Yes | No  | Yes |
| 2076-92G | IBM FlashSystem 7000 High Density LFF Expansion Enclosure | System             | Other Storage   | Yes | No  | Yes |
| 2076-A9F | V7000F HD LFF Expansion                                   | Expansion Unit     | Other Storage   | Yes | No  | Yes |
| 2076-AF6 | Storwize V7000F Control                                   | System             | Other Storage   | Yes | Yes | Yes |
| 2076-AFF | Storwize V7000F Expansion                                 | Expansion Unit     | Other Storage   | Yes | No  | Yes |
| 2076-U7A | V7000 Utility Model SFF Control                           | System             | Other Storage   | Yes | No  | Yes |
| 2076-U7B | IBM Storwize V7000 Utility Model NVMe Control Enclosure   | System             | Other Storage   | Yes | Yes | Yes |
| 2076-U7C | IBM FlashSystem 7200 Utility NVMe Control Enclosure       | System             | Other Storage   | Yes | Yes | Yes |
| 2077-112 | V5010 LFF Control   | System             | Other Storage   | Yes | Yes | Yes |
| 2077-124 | V5010 SFF Control   | System             | Other Storage   | Yes | Yes | Yes |
| 2077-12F | V5000 LFF Expansion                                       | Expansion Unit     | Other Storage   | Yes | No  | Yes |
| 2077-12G | IBM FlashSystem 5100 LFF Expansion Enclosure              | System             | Other Storage   | Yes | No  | Yes |
| 2077-212 | V5020 LFF Control   | System             | Other Storage   | Yes | Yes | Yes |
| 2077-224 | V5020 SFF Control   | System             | Other Storage   | Yes | Yes | Yes |
| 2077-24F | V5000 SFF Expansion                                       | Expansion Unit     | Other Storage   | Yes | No  | Yes |
| 2077-24G | IBM FlashSystem 5100 SFF Expansion Enclosure              | System             | Other Storage   | Yes | No  | Yes |
| 2077-312 | V5030 LFF Control   | System             | Other Storage   | Yes | Yes | Yes |
| 2077-324 | V5030 SFF Control   | System             | Other Storage   | Yes | Yes | Yes |
| 2077-424 | IBM Storwize V5100 NVMe Control Enclosure                 | System             | Other Storage   | Yes | Yes | Yes |
| 2077-4H4 | IBM FlashSystem 5100 NVMe Control Enclosure               | System             | Other Storage   | Yes | Yes | Yes |
| 2077-92F | V5000 HD LFF Expansion                                    | Expansion Unit     | Other Storage   | Yes | No  | Yes |
| 2077-92G | IBM FlashSystem 5100 High Density Expansion               | System             | Other Storage   | Yes | No  | Yes |
| 2077-A9F | V5030F HD LFF Expansion                                   | Expansion Unit     | Other Storage   | Yes | No  | Yes |
| 2077-AF3 | Storwize V5030F Control                                   | System             | Other Storage   | Yes | Yes | Yes |
| 2077-AF4 | IBM Storwize V5100F NVMe Control Enclosure                | System             | Other Storage   | Yes | Yes | Yes |
| 2077-AFF | Storwize V5030F Expansion                                 | Expansion Unit     | Other Storage   | Yes | No  | Yes |
| 2078-112 | V5010 LFF Control   | System             | Other Storage   | Yes | Yes | Yes |
| 2078-124 | V5010 SFF Control   | System             | Other Storage   | Yes | Yes | Yes |
| 2078-12F | V5000 LFF Expansion                                       | Expansion Unit     | Other Storage   | Yes | No  | Yes |
| 2078-12G | IBM FlashSystem 5100 LFF Expansion Enclosure              | System             | Other Storage   | Yes | No  | Yes |
| 2078-212 | V5020 LFF Control   | System             | Other Storage   | Yes | Yes | Yes |
| 2078-224 | V5020 SFF Control   | System             | Other Storage   | Yes | Yes | Yes |
| 2078-24C | V5000 SFF Control   | System             | Other Storage   | Yes | No  | Yes |

|          |  |                |                |     |     |     |
|----------|--|----------------|----------------|-----|-----|-----|
| 2078-24F | V5000 SFF Expansion  | Expansion Unit | Other Storage  | Yes | No  | Yes |
| 2078-24G | IBM FlashSystem 5100 SFF Expansion Enclosure                 | System         | Other Storage  | Yes | No  | Yes |
| 2078-312 | V5030 LFF Control  | System         | Other Storage  | Yes | Yes | Yes |
| 2078-324 | V5030 SFF Control  | System         | Other Storage  | Yes | Yes | Yes |
| 2078-424 | IBM Storwize V5100 NVMe Control Enclosure                    | System         | Other Storage  | Yes | Yes | Yes |
| 2078-4H4 | IBM FlashSystem 5100 NVMe Control Enclosure                  | System         | Other Storage  | Yes | Yes | Yes |
| 2078-92F | V5000 HD LFF Expansion                                       | Expansion Unit | Other Storage  | Yes | No  | Yes |
| 2078-92G | IBM FlashSystem 5100 High Density Expansion Enclosure        | System         | Other Storage  | Yes | No  | Yes |
| 2078-A9F | V5030F HD LFF Expansion                                      | Expansion Unit | Other Storage  | Yes | No  | Yes |
| 2078-AF3 | Storwize V5030F Control                                      | System         | Other Storage  | Yes | Yes | Yes |
| 2078-AF4 | IBM Storwize V5100F NVMe Control Enclosure                   | System         | Other Storage  | Yes | Yes | Yes |
| 2078-AFF | Storwize V5030F Expansion                                    | Expansion Unit | Other Storage  | Yes | No  | Yes |
| 2078-U5A | V5030 Utility Model SFF Control                              | System         | Other Storage  | Yes | No  | Yes |
| 2078-U5B | IBM Storwize V5100 Utility NVMe Control Enclosure            | System         | Other Storage  | Yes | No  | Yes |
| 2078-UHB | IBM FlashSystem 5100 Utility NVMe Control Enclosure          | System         | Other Storage  | Yes | Yes | Yes |
| 2145-12F | SVC LFF Expansion Enclosure                                  | System         | Other Storage  | Yes | No  | Yes |
| 2145-24F | SVC SFF Expansion Enclosure                                  | System         | Other Storage  | Yes | No  | Yes |
| 2145-92F | SVC HD LFF Expansion   | Expansion Unit | Other Storage  | Yes | No  | Yes |
| 2145-SV1 | SVC Storage Engine   | System         | Other Storage  | Yes | Yes | Yes |
| 2145-SV3 | IBM SAN Volume Controller Storage Engine                     | System         | Other Storage  | Yes | No  | Yes |
| 2147-24F | SVC SFF expansion enclosure                                  | System         | Other Storage  | Yes | No  | Yes |
| 2147-92F | SVC HD LFF Expansion   | Expansion Unit | Other Storage  | Yes | No  | Yes |
| 2147-SV1 | SVC Storage Engine   | System         | Other Storage  | Yes | Yes | Yes |
| 2147-SV3 | IBM SAN Volume Controller Storage Engine                     | System         | Other Storage  | Yes | No  | Yes |
| 2498-B24 | IBM System Storage SAN24B-4 Express                          | System         | SANBLE         | Yes | No  | Yes |
| 2498-F24 | IBM System Storage SAN24B-5                                  | System         | SANBLE         | Yes | No  | Yes |
| 2498-F48 | IBM System Storage SAN48B-5                                  | System         | SANBLE         | Yes | No  | Yes |
| 2498-F96 | IBM System Networking SAN96B-5                               | System         | SANBLE         | Yes | No  | Yes |
| 2498-N96 | IBM System Networking SAN96B-5                               | System         | SANBLE         | Yes | No  | Yes |
| 2498-R06 | IBM 2498 System Storage SAN06N-R Model R06                   | System         | SANBLE         | Yes | No  | Yes |
| 2498-R42 | IBM System Storage SAN42B-R                                  | System         | SANBLE         | Yes | No  | Yes |
| 2498-X24 | IBM System Networking SAN24B-5                               | System         | SANBLE         | Yes | No  | Yes |
| 2499-416 | IBM System Storage SAN384B-2                                 | System         | SANBHE         | Yes | No  | Yes |
| 2499-816 | IBM System Storage SAN768B-2                                 | System         | SANBHE         | Yes | No  | Yes |
| 2831-980 | DS8884   | System         | High End Disk  | Yes | Yes | Yes |
| 2831-981 | DS8886   | System         | High End Disk  | Yes | Yes | Yes |
| 2831-982 | DS8888   | System         | High End Disk  | Yes | Yes | Yes |
| 2831-984 | DS8884   | System         | High End Disk  | Yes | Yes | Yes |
| 2831-985 | DS8886   | System         | High End Disk  | Yes | Yes | Yes |
| 2831-986 | DS8886   | System         | High End Disk  | Yes | Yes | Yes |
| 2832-980 | DS8884   | Expansion Unit | High End Disk  | Yes | Yes | Yes |
| 2832-981 | DS8886   | Expansion Unit | High End Disk  | Yes | Yes | Yes |
| 2832-982 | DS8888   | System         | High End Disk  | Yes | Yes | Yes |
| 2832-984 | DS8884   | System         | High End Disk  | Yes | Yes | Yes |
| 2832-985 | DS8886   | System         | High End Disk  | Yes | Yes | Yes |
| 2832-986 | DS8886   | System         | High End Disk  | Yes | Yes | Yes |
| 2833-980 | DS8884   | System         | High End Disk  | Yes | Yes | Yes |
| 2833-981 | DS8886   | System         | High End Disk  | Yes | Yes | Yes |
| 2833-982 | DS8888   | System         | High End Disk  | Yes | Yes | Yes |
| 2833-984 | DS8884   | System         | High End Disk  | Yes | Yes | Yes |
| 2833-985 | DS8886   | System         | High End Disk  | Yes | Yes | Yes |
| 2833-986 | DS8886   | System         | High End Disk  | Yes | Yes | Yes |
| 2834-980 | DS8884   | System         | High End Disk  | Yes | Yes | Yes |
| 2834-981 | DS8886   | System         | High End Disk  | Yes | Yes | Yes |
| 2834-982 | DS8888   | System         | High End Disk  | Yes | Yes | Yes |
| 2834-984 | DS8884   | System         | High End Disk  | Yes | Yes | Yes |
| 2834-985 | DS8886   | System         | High End Disk  | Yes | Yes | Yes |
| 2834-986 | DS8886   | System         | High End Disk  | Yes | Yes | Yes |
| 3555-L3A | TS4300 Tape Library  | Expansion Unit | Mid Range Tape | Yes | No  | Yes |
| 3572-S5H | TS2900 Tape Autoloader w/LTO5 HH SAS drive                   | System         | Mid Range Tape | Yes | No  | Yes |
| 3572-S6H | TS2900 Tape Library with LTO6 HH SAS drive & rack mount kit  | System         | Mid Range Tape | Yes | No  | Yes |
| 3572-S7H | TS2900 Tape Autoloader with LTO Ultrium 7 Half-high SAS Tape | System         | Mid Range Tape | Yes | No  | Yes |
| 3572-S8H | TS2900 Tape Autoloader with LTO Ultrium 8 Half-high SAS Tape | System         | Mid Range Tape | Yes | No  | Yes |
| 3573-L2U | TS3100 Tape Library Model L2U                                | System         | Mid Range Tape | Yes | No  | Yes |
| 3573-L4U | TS3200 Tape Library Model L4U                                | System         | Mid Range Tape | Yes | No  | Yes |
| 3576-E9U | IBM System Storage TS3310 Tape Library Model E9U             | System         | Mid Range Tape | Yes | No  | Yes |
| 3576-L5B | IBM System Storage TS3310 Tape Library Model L5B             | System         | Mid Range Tape | Yes | No  | Yes |
| 3580-H5S | System Storage TS2250 Tape Drive Express Model H5S           | System         | Mid Range Tape | Yes | No  | Yes |
| 3580-H7S | TS2270 Tape Drive Model H7S with HHLTO7 SAS Tape Drive with  | System         | Mid Range Tape | Yes | No  | Yes |
| 3580-H8S | TS2280 Tape Drive Model H8S with HHLTO8 SAS Tape Drive with  | System         | Mid Range Tape | Yes | No  | Yes |
| 3580-S53 | System Storage TS2350 Tape Drive Express Model S53           | System         | Mid Range Tape | Yes | No  | Yes |
| 3580-S63 | System Storage TS2360 Tape Drive Model S63                   | System         | Mid Range Tape | Yes | No  | Yes |
| 3584-D23 | IBM System Storage TS3500 Tape Library Model D23             | System         | Tape Products  | Yes | No  | Yes |
| 3584-D25 | TS4500 HD2 Expansion Frame                                   | System         | Tape Products  | Yes | No  | Yes |
| 3584-D55 | TS4500 HD2 Expansion Frame                                   | System         | Tape Products  | Yes | No  | Yes |

|          |   |                |               |     |     |     |
|----------|---|----------------|---------------|-----|-----|-----|
| 3584-HA1 | IBM TotalStorage 3584 High Availability Frame Model HA1       | System         | Tape Products | Yes | No  | Yes |
| 3584-L23 | IBM System Storage TS3500 Tape Library Model L23              | System         | Tape Products | Yes | No  | Yes |
| 3584-L25 | TS4500 HD2 Base Frame   | System         | Tape Products | Yes | No  | Yes |
| 3584-L53 | IBM System Storage TS3500 Tape Library Model L53              | System         | Tape Products | Yes | No  | Yes |
| 3584-L55 | TS4500 HD2 Base Frame   | System         | Tape Products | Yes | No  | Yes |
| 3584-S25 | TS4500 HD2 Expansion Frame                                    | System         | Tape Products | Yes | No  | Yes |
| 3584-S55 | TS4500 HD2 Expansion Frame                                    | System         | Tape Products | Yes | No  | Yes |
| 3588-F4A | IBM System Storage TS1040 Tape Drive Model F4A                | System         | Tape Products | Yes | No  | Yes |
| 3588-F5A | IBM System Storage TS1050 Tape Drive Model F5A                | System         | Tape Products | Yes | No  | Yes |
| 3588-F6A | IBM System Storage TS1060 Tape Drive Model F6A                | System         | Tape Products | Yes | No  | Yes |
| 3588-F7C | TS1070 Ultrium 7 Tape Drive                                   | System         | Tape Products | Yes | No  | Yes |
| 3588-F8A | TS1080 Ultrium 8 Tape Drive                                   | System         | Tape Products | Yes | No  | Yes |
| 3588-F8C | TS1080 Ultrium 8 Tape Drive                                   | System         | Tape Products | Yes | No  | Yes |
| 3588-F8S | IBM TS1080 Tape Drive LTO8 Single Mode Fiber                  | System         | Tape Products | Yes | No  | Yes |
| 3592-60F | IBM TS1160 Tape Drive Model 60F                               | Expansion Unit | High End Tape | Yes | Yes | Yes |
| 3592-60G | TS1160 Tape Drive Model 60G                                   | System         | High End Tape | Yes | Yes | Yes |
| 3592-70F | TS1170 Tape Drive Model 70F                                   | System         | High End Tape | Yes | Yes | Yes |
| 3592-70S | TS1170 Tape Drive Model 70S                                   | System         | High End Tape | Yes | Yes | Yes |
| 3592-EH8 | IBM TS1150 HD2 Tape Drive Model EH8                           | System         | High End Tape | Yes | Yes | Yes |
| 3957-VEC | TS7700 Server   | System         | High End Tape | Yes | Yes | Yes |
| 3957-VED | TS7770 Server   | System         | High End Tape | Yes | Yes | Yes |
| 4657-12G | IBM FlashSystem 7000 LFF Expansion Enclosure                  | System         | Solutions     | Yes | No  | Yes |
| 4657-24G | IBM FlashSystem 7000 SFF Expansion Enclosure                  | System         | Solutions     | Yes | No  | Yes |
| 4657-924 | IBM FlashSystem 7300 NVMe Control Enclosure                   | System         | Solutions     | Yes | Yes | Yes |
| 4657-92G | IBM FlashSystem 7000 High Density LFF Expansion Enclosure     | System         | Solutions     | Yes | No  | Yes |
| 4657-U7D | IBM FlashSystem 7300 Utility Model NVMe Control Enclosure     | System         | Solutions     | Yes | Yes | Yes |
| 4662-12G | IBM FlashSystem 5200 LFF Expansion Enclosure                  | System         | Other Storage | Yes | No  | Yes |
| 4662-24G | IBM FlashSystem 5200 SFF Expansion Enclosure                  | System         | Other Storage | Yes | No  | Yes |
| 4662-6H2 | IBM FlashSystem 5200 NVMe Control Enclosure                   | System         | Other Storage | Yes | Yes | Yes |
| 4662-92G | IBM FlashSystem 5200 High Density Expansion Enclosure         | System         | Other Storage | Yes | No  | Yes |
| 4662-F12 | IBM FlashSystem 5200 LFF Expansion Enclosure                  | System         | Other Storage | Yes | Yes | Yes |
| 4662-F24 | IBM FlashSystem 5200 SFF Expansion Enclosure                  | System         | Other Storage | Yes | Yes | Yes |
| 4662-F92 | IBM FlashSystem 5200 High Density LFF Expansion Enclosure     | System         | Other Storage | Yes | Yes | Yes |
| 4662-UH6 | IBM FlashSystem 5200 Utility NVMe Control Enclosure           | System         | Other Storage | Yes | Yes | Yes |
| 4662-Y12 | IBM FlashSystem 5200 NVMe Control Enclosure                   | System         | Other Storage | Yes | Yes | Yes |
| 4666-AH8 | IBM FlashSystem 9500 SFF NVMe Control Enclosure               | System         | Other Storage | Yes | Yes | Yes |
| 4666-UH8 | IBM FlashSystem 9500 Utility Model SFF NVMe Control Enclosure | System         | Other Storage | Yes | Yes | Yes |
| 4680-12H | IBM Storage FlashSystem 5045 LFF Expansion Enclosure          | System         | Solutions     | Yes | Yes | Yes |
| 4680-24H | IBM Storage FlashSystem 5045 SFF Expansion Enclosure          | System         | Solutions     | Yes | Yes | Yes |
| 4680-2P2 | IBM Storage FlashSystem 5015 LFF Control Enclosure            | System         | Solutions     | Yes | Yes | Yes |
| 4680-2P4 | IBM Storage FlashSystem 5015 SFF Control Enclosure            | System         | Solutions     | Yes | Yes | Yes |
| 4680-3P2 | IBM Storage FlashSystem 5045 LFF Control Enclosure            | System         | Solutions     | Yes | Yes | Yes |
| 4680-3P4 | IBM Storage FlashSystem 5045 SFF Control Enclosure            | System         | Solutions     | Yes | Yes | Yes |
| 4680-92H | IBM Storage FlashSystem 5045 HD LFF Expansion Enclosure       | System         | Solutions     | Yes | Yes | Yes |
| 5331-983 | IBM DS8882F   | System         | High End Disk | Yes | Yes | Yes |
| 5331-984 | DS8884  | System         | High End Disk | Yes | Yes | Yes |
| 5331-985 | DS8886  | System         | High End Disk | Yes | Yes | Yes |
| 5331-986 | DS8886  | System         | High End Disk | Yes | Yes | Yes |
| 5331-988 | DS8888  | System         | High End Disk | Yes | Yes | Yes |
| 5331-993 | IBM DS8910F   | System         | High End Disk | Yes | Yes | Yes |
| 5331-994 | IBM DS8910F   | System         | High End Disk | Yes | Yes | Yes |
| 5331-996 | IBM DS8950F   | System         | High End Disk | Yes | Yes | Yes |
| 5331-998 | IBM DS8980F   | System         | High End Disk | Yes | Yes | Yes |
| 5331-E96 | IBM DS8950F Expansion Unit                                    | Expansion Unit | High End Disk | Yes | Yes | Yes |
| 5332-983 | IBM DS8882F   | System         | High End Disk | Yes | Yes | Yes |
| 5332-984 | DS8884  | System         | High End Disk | Yes | Yes | Yes |
| 5332-985 | DS8886  | System         | High End Disk | Yes | Yes | Yes |
| 5332-986 | DS8886  | System         | High End Disk | Yes | Yes | Yes |
| 5332-988 | DS8888  | System         | High End Disk | Yes | Yes | Yes |
| 5332-993 | IBM DS8910F   | System         | High End Disk | Yes | Yes | Yes |
| 5332-994 | IBM DS8910F   | System         | High End Disk | Yes | Yes | Yes |
| 5332-996 | IBM DS8950F   | System         | High End Disk | Yes | Yes | Yes |
| 5332-998 | IBM DS8980F   | System         | High End Disk | Yes | Yes | Yes |
| 5332-E96 | IBM DS8950F Expansion Unit                                    | System         | High End Disk | Yes | Yes | Yes |
| 5333-983 | IBM DS8882F   | System         | High End Disk | Yes | Yes | Yes |
| 5333-984 | DS8884  | System         | High End Disk | Yes | Yes | Yes |
| 5333-985 | DS8886  | System         | High End Disk | Yes | Yes | Yes |
| 5333-986 | DS8886  | System         | High End Disk | Yes | Yes | Yes |
| 5333-988 | DS8888  | System         | High End Disk | Yes | Yes | Yes |
| 5333-993 | IBM DS8910F   | System         | High End Disk | Yes | Yes | Yes |
| 5333-994 | IBM DS8910F   | System         | High End Disk | Yes | Yes | Yes |
| 5333-996 | IBM DS8950F   | System         | High End Disk | Yes | Yes | Yes |
| 5333-998 | IBM DS8980F   | System         | High End Disk | Yes | Yes | Yes |
| 5333-E96 | IBM DS8950F Expansion Unit                                    | Expansion Unit | High End Disk | Yes | Yes | Yes |
| 5334-983 | IBM DS8882F   | System         | High End Disk | Yes | Yes | Yes |

|          |   |                |                        |     |     |     |
|----------|---|----------------|------------------------|-----|-----|-----|
| 5334-984 | DS8884  | System         | High End Disk          | Yes | Yes | Yes |
| 5334-985 | DS8886  | System         | High End Disk          | Yes | Yes | Yes |
| 5334-986 | DS8886  | System         | High End Disk          | Yes | Yes | Yes |
| 5334-988 | DS8888  | System         | High End Disk          | Yes | Yes | Yes |
| 5334-993 | IBM DS8910F   | System         | High End Disk          | Yes | Yes | Yes |
| 5334-994 | IBM DS8910F   | System         | High End Disk          | Yes | Yes | Yes |
| 5334-996 | IBM DS8950F   | System         | High End Disk          | Yes | Yes | Yes |
| 5334-998 | IBM DS8980F   | System         | High End Disk          | Yes | Yes | Yes |
| 5334-E96 | IBM DS8950F Expansion Unit                                | Expansion Unit | High End Disk          | Yes | Yes | Yes |
| 5341-993 | IBM DS8910F   | System         | High End Disk          | Yes | Yes | Yes |
| 5341-994 | IBM DS8910F   | System         | High End Disk          | Yes | Yes | Yes |
| 5341-996 | IBM DS8950F   | System         | High End Disk          | Yes | Yes | Yes |
| 5341-998 | IBM DS8980F   | System         | High End Disk          | Yes | Yes | Yes |
| 5341-E96 | IBM DS8950F Expansion Unit                                | System         | High End Disk          | Yes | Yes | Yes |
| 7042-C08 | Desktop Hardware Management Console                       | System         | eServer                | Yes | No  | Yes |
| 7042-CR5 | IBM 7042-CR5  | System         | eServer                | Yes | No  | Yes |
| 7042-CR6 | Rack-mount Hardware Management Console                    | System         | eServer                | Yes | No  | Yes |
| 7042-CR7 | Rack-mount Hardware Management Console                    | System         | eServer                | Yes | No  | Yes |
| 7042-CR8 | Rack-mount Hardware Management Console                    | System         | eServer                | Yes | No  | Yes |
| 7042-CR9 | Rack-mount Hardware Management Console                    | System         | eServer                | Yes | No  | Yes |
| 7063-CR1 | Hardware Management Console                               | System         | eServer                | Yes | No  | Yes |
| 7063-CR2 | Hardware Management Console                               | System         | eServer                | Yes | No  | Yes |
| 7214-1U2 | IBM System Storage 7214 Tape and DVD Enclosure Express    | System         | Complementary Stor Prd | Yes | No  | Yes |
| 7216-1U2 | IBM System Storage 7216 Multi-Media Enclosure (Model 1U2) | System         | Complementary Stor Prd | Yes | No  | Yes |
| 7226-1U3 | IBM 7226-1U3  | System         | Mid Range Tape         | Yes | No  | Yes |
| 7310-C03 | IBM 7310-C03  | System         | pSeries                | Yes | No  | Yes |
| 7310-C04 | IBM 7310-C04  | System         | pSeries                | Yes | No  | Yes |
| 7310-C05 | IBM 7310-C05  | System         | pSeries                | Yes | No  | Yes |
| 7310-C06 | IBM 7310-C06  | System         | pSeries                | Yes | No  | Yes |
| 7310-CR2 | IBM 7310-CR2  | System         | pSeries                | Yes | No  | Yes |
| 7310-CR3 | IBM 7310-CR3  | System         | pSeries                | Yes | No  | Yes |
| 7310-CR4 | IBM 7310-CR4  | System         | pSeries                | Yes | No  | Yes |
| 8202-E4C | IBM Power 720   | System         | eServer                | Yes | No  | Yes |
| 8202-E4D | IBM Power 720   | System         | eServer                | Yes | No  | Yes |
| 8205-E6B | IBM Power 740   | System         | eServer                | Yes | No  | Yes |
| 8247-21L | IBM Power System S812L                                    | System         | eServer                | Yes | No  | Yes |
| 8247-22L | IBM Power System S822L                                    | System         | eServer                | Yes | No  | Yes |
| 8247-42L | IBM Power Systems S824L                                   | System         | eServer                | Yes | No  | Yes |
| 8284-21A | IBM Power System S812                                     | System         | eServer                | Yes | No  | Yes |
| 8284-22A | IBM Power System S822                                     | System         | eServer                | Yes | No  | Yes |
| 8286-41A | IBM Power System S814                                     | System         | eServer                | Yes | No  | Yes |
| 8286-42A | IBM Power System S824                                     | System         | eServer                | Yes | No  | Yes |
| 8374-01M | PurePower Rack-mount Hardware Management Console          | System         | eServer                | Yes | No  | Yes |
| 8408-44E | IBM Power E850C   | System         | eServer                | Yes | No  | Yes |
| 8408-E8E | IBM Power E850  | System         | eServer                | Yes | No  | Yes |
| 8960-F24 | IBM Storage Networking SAN24B-6                           | System         | SANBLE                 | Yes | No  | Yes |
| 8960-F96 | IBM Storage Networking SAN128B-6                          | Expansion Unit | SANBLE                 | Yes | No  | Yes |
| 8960-N64 | IBM Storage Networking SAN64B-6                           | System         | SANBLE                 | Yes | No  | Yes |
| 8960-N96 | IBM Storage Networking SAN128B-6                          | Expansion Unit | SANBLE                 | Yes | No  | Yes |
| 8960-P64 | IBM Storage Networking SAN64B-7                           | System         | SANBLE                 | Yes | No  | Yes |
| 8960-R18 | IBM Storage Networking SAN18B-6                           | Expansion Unit | SANBLE                 | Yes | No  | Yes |
| 8960-R64 | IBM Storage Networking SAN64B-7                           | System         | SANBLE                 | Yes | No  | Yes |
| 8961-F04 | IBM Storage Networking SAN256B-6                          | System         | SANBHE                 | Yes | No  | Yes |
| 8961-F08 | IBM Storage Networking SAN512B-6                          | System         | SANBHE                 | Yes | No  | Yes |
| 8961-F74 | IBM Storage Networking SAN256B-7                          | System         | SANBHE                 | Yes | No  | Yes |
| 8961-F78 | IBM Storage Networking SAN512B-7                          | System         | SANBHE                 | Yes | No  | Yes |
| 8969-F24 | IBM Storage Networking SAN24B-6                           | System         | SANBLE                 | Yes | No  | Yes |
| 8969-R42 | IBM Storage Networking SAN42B-R7                          | System         | SANBLE                 | Yes | No  | Yes |
| 8977-R16 | IBM Storage Networking SAN16C-R                           | System         | SANCLE                 | Yes | No  | Yes |
| 8977-R50 | IBM Storage Networking SAN50C-R                           | Expansion Unit | SANCLE                 | Yes | No  | Yes |
| 8977-T32 | IBM Storage Networking SAN32C-6                           | Expansion Unit | SANCLE                 | Yes | No  | Yes |
| 8977-T48 | IBM Storage Networking SAN48C-6                           | Expansion Unit | SANCLE                 | Yes | No  | Yes |
| 8977-T96 | IBM Storage Networking SAN96C-6                           | Expansion Unit | SANCLE                 | Yes | No  | Yes |
| 8978-E04 | IBM Storage Networking SAN192C-6                          | System         | SANCLE                 | Yes | No  | Yes |
| 8978-E08 | IBM Storage Networking SAN384C-6                          | System         | SANCLE                 | Yes | No  | Yes |
| 9008-22L | IBM Power System L922                                     | System         | eServer                | Yes | No  | Yes |
| 9009-22A | IBM Power System S922                                     | System         | eServer                | Yes | No  | Yes |
| 9009-22G | IBM Power System S922                                     | System         | eServer                | Yes | No  | Yes |
| 9009-41A | IBM Power System S914                                     | System         | eServer                | Yes | No  | Yes |
| 9009-41G | IBM Power System S914                                     | System         | eServer                | Yes | No  | Yes |
| 9009-42A | IBM Power System S924                                     | System         | eServer                | Yes | No  | Yes |
| 9009-42G | IBM Power System S924                                     | System         | eServer                | Yes | No  | Yes |
| 9040-MR9 | IBM Power System E950                                     | System         | eServer                | Yes | No  | Yes |
| 9043-MRX | IBM Power System E1050                                    | System         | eServer                | Yes | Yes | Yes |
| 9080-HEX | IBM Power E1080   | System         | eServer                | Yes | No  | Yes |

|          |   |                |               |     |      |     |
|----------|---|----------------|---------------|-----|------|-----|
| 9080-M9S | IBM Power System E980                                     | System         | eServer       | Yes | No   | Yes |
| 9080-MHE | IBM Power System E880C                                    | System         | eServer       | Yes | No   | Yes |
| 9080-MME | IBM Power System E870C                                    | System         | eServer       | Yes | No   | Yes |
| 9105-22A | IBM Power S1022   | System         | eServer       | Yes | Yes  | Yes |
| 9105-22B | IBM Power S1022s  | System         | eServer       | Yes | Yes  | Yes |
| 9105-41B | IBM Power S1014   | System         | eServer       | Yes | Yes  | Yes |
| 9105-42A | IBM Power S1024   | System         | eServer       | Yes | Yes  | Yes |
| 9119-MHE | IBM Power System E880                                     | System         | eServer       | Yes | No   | Yes |
| 9119-MME | IBM Power System E870                                     | System         | eServer       | Yes | No   | Yes |
| 9223-22H | IBM Power System H922                                     | System         | eServer       | Yes | No   | Yes |
| 9223-22S | IBM Power System H922                                     | System         | eServer       | Yes | No   | Yes |
| 9223-42H | IBM Power System H924                                     | System         | eServer       | Yes | No   | Yes |
| 9223-42S | IBM Power System H924                                     | System         | eServer       | Yes | No   | Yes |
| 9710-E06 | Cisco MDS 9706 Multilayer Director for IBM System Storage | System         | SANCHE        | Yes | No   | Yes |
| 9786-22H | IBM Power L1022   | System         | eServer       | Yes | Yes  | Yes |
| 9786-42H | IBM Power L1024   | System         | eServer       | Yes | Yes  | Yes |
| 9840-AE3 | IBM FlashSystem 900                                       | System         | Other Storage | Yes | Yes  | Yes |
| 9843-AE3 | IBM FlashSystem 900                                       | System         | Other Storage | Yes | Yes  | Yes |
| 9846-12F | IBM FlashSystem V9000 LFF Expansion Enclosure             | Expansion Unit | Other Storage | Yes | No   | Yes |
| 9846-24F | V9000 SFF Expansion Enclosure                             | Expansion Unit | Other Storage | Yes | No   | Yes |
| 9846-92F | V9000 HD Expansion Enclosure                              | Expansion Unit | Other Storage | Yes | No   | Yes |
| 9846-A9F | IBM FlashSystem 9100 High Density LFF Expansion Enclosure | System         | Other Storage | Yes | No   | Yes |
| 9846-AC3 | IBM FlashSystem Control Enclosure                         | Expansion Unit | Other Storage | Yes | Yes  | Yes |
| 9846-AE3 | IBM FlashSystem V9000 Storage Enclosure                   | System         | Other Storage | Yes | Yes  | Yes |
| 9846-AF7 | IBM FlashSystem 9110 SFF NVMe Control Enclosure           | System         | Other Storage | Yes | Yes  | Yes |
| 9846-AF8 | IBM FlashSystem 9150 SFF NVMe Control Enclosure           | System         | Other Storage | Yes | Yes  | Yes |
| 9846-AFF | IBM FlashSystem 9100 SFF Expansion Enclosure              | System         | Other Storage | Yes | No   | Yes |
| 9846-AG8 | IBM FlashSystem 9200 SFF NVMe Control Enclosure           | System         | Other Storage | Yes | No   | Yes |
| 9848-12F | IBM FlashSystem V9000 LFF Expansion Enclosure             | Expansion Unit | Other Storage | Yes | No   | Yes |
| 9848-24F | V9000 SFF Expansion Enclosure                             | Expansion Unit | Other Storage | Yes | No   | Yes |
| 9848-92F | V9000 HD Expansion Enclosure                              | Expansion Unit | Other Storage | Yes | No   | Yes |
| 9848-AC3 | IBM FlashSystem Control Enclosure                         | Expansion Unit | Other Storage | Yes | Yes  | Yes |
| 9848-AE2 | IBM FlashSystem V9000 Storage Enclosure                   | Expansion Unit | Other Storage | Yes | Yes  | Yes |
| 9848-AE3 | IBM FlashSystem V9000 Storage Enclosure                   | System         | Other Storage | Yes | Yes  | Yes |
| 9848-AF7 | IBM FlashSystem 9110 SFF NVMe Control Enclosure           | System         | Other Storage | Yes | Yes  | Yes |
| 9848-AF8 | IBM FlashSystem 9150 SFF NVMe Control Enclosure           | System         | Other Storage | Yes | Yes  | Yes |
| 9848-AG8 | IBM FlashSystem 9200 SFF NVMe Control Enclosure           | System         | Other Storage | Yes | #N/A | Yes |