



## Independent Software Vendor Matrix (ISV) for IBM Tape

Last updated: Feb 13, 2026  
© Copyright IBM Corporation 2026.

References in this document to IBM products or services do not imply that IBM intends to make them available in every country.

IBM, the IBM logo, and [ibm.com](http://ibm.com) are trademarks or registered trademarks of International Business Machines Corporation in the United States, other countries, or both. If these and other IBM trademarked terms are marked on their first occurrence in this information with a trademark symbol (® or ™), these symbols indicate U.S. registered or common law trademarks owned by IBM at the time this information was published. Such trademarks may also be registered or common law trademarks in other countries. A current list of IBM trademarks is available on the Web at "Copyright and trademark information" at [www.ibm.com/legal/copytrade.shtml](http://www.ibm.com/legal/copytrade.shtml).

Microsoft, Windows, and the Windows logo are trademarks of Microsoft Corporation in the United States, other countries, or both.

Intel, Intel Inside (logos), MMX, and Pentium are trademarks of Intel Corporation in the United States, other countries, or both.

Linux is a trademark of Linus Torvalds in the United States, other countries, or both.

Linear Tape-Open, LTO, the LTO Logo, Ultrium, and the Ultrium logo are trademarks of HPE, IBM Corp. and Quantum in the U.S. and other countries.

Other company, product, or service names may be trademarks or service marks of others.

Information is provided "AS IS" without warranty of any kind.

All customer examples described are presented as illustrations of how those customers have used IBM products and the results they may have achieved. Actual environmental costs and performance characteristics may vary by customer.

Information concerning non-IBM products was obtained from a supplier of these products, published announcement material, or other publicly available sources and does not constitute an endorsement of such products by IBM. Sources for non-IBM list prices and performance numbers are taken from publicly available information, including vendor announcements and vendor worldwide homepages. IBM has not tested these products and cannot confirm the accuracy of performance, capability, or any other claims related to non-IBM products. Questions on the capability of non-IBM products should be addressed to the supplier of those products.

All statements regarding IBM future direction and intent are subject to change or withdrawal without notice and represent goals and objectives only. Contact your local IBM office or IBM authorized reseller for the full text of the specific Statement of Direction.

**THE INFORMATION IN THIS DOCUMENT IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY, OR COMPATIBILITY.**



Some information addresses anticipated future capabilities. Such information is not intended as a definitive statement of a commitment to specific levels of performance, function or delivery schedules with respect to any future products. Such commitments are only made in IBM product announcements. The information is presented here to communicate IBM's current investment and development activities as a good faith effort to help with our customers' future planning.

Performance is based on measurements and projections using standard IBM benchmarks in a controlled environment. The actual throughput or performance that any user will experience will vary depending upon considerations such as the amount of multiprogramming in the user's job stream, the I/O configuration, the storage configuration, and the workload processed. Therefore, no assurance can be given that an individual user will achieve throughput or performance improvements equivalent to the ratios stated here. Photographs shown are of engineering prototypes. Changes may be incorporated in production models.

Any references in this information to non-IBM websites are provided for convenience only and do not in any manner serve as an endorsement of those websites. The materials at those websites are not part of the materials for this IBM product and use of those websites is at your own risk.

Product Reference:

3580: [IBM 3580 Tape Drive](#)  
TS4300 (3573): [IBM TS4300 Tape Drive](#)  
TS3500 (3584): [IBM TS3500 Tape Library](#)  
TS4500 (3584): [IBM TS4500 Tape Library](#)  
Diamondback (3584): [IBM Diamondback Tape Library](#)  
TS1150 (3562): [IBM TS1150 Tape Drive](#)  
TS1160 (3592): [IBM TS1160 Tape Drive](#)  
TS1170 (3592): [IBM TS1170 Tape Drive](#)  
Deep Archive: [IBM Storage Deep Archive](#)

**THE INFORMATION IN THIS DOCUMENT IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY, OR COMPATIBILITY.**



The following is a list of independent software vendors (ISVs) who have indicated support for the listed product. **Each completed cell indicates supported by the ISV for the software indicated.**

|  |                                    |
|--|------------------------------------|
| <b>Arcitecta: Mediaflux -&gt; <a href="#">website</a></b>      |                                    |
| <b>Operating System</b>  | <b>Deep Archive on Diamondback</b> |
|  | LTO 9 SAS<br>LTO 10 SAS            |
| Linux  | •                                  |
| <b>Notes:</b> Mediaflux supports Deep Archive Tape Barcode API |                                    |

|   |                                  |                                  |                                  |                                  |        |
|---|----------------------------------|----------------------------------|----------------------------------|----------------------------------|--------|
| <b>Arctera: Backup Exec → <a href="#">website</a></b>   |                                  |                                  |                                  |                                  |        |
| <b>Notes on ISV site navigation:</b>  |                                  |                                  |                                  |                                  |        |
| <ul style="list-style-type: none"> <li>On the website above, enter "Backup Exec" in the Product Lookup box. Select "Backup Exec for Windows Servers" or any other Backup Exec version of interest. Click on arrow.</li> <li>On the following page, click the "Compatibility List" link in the right column.</li> <li>From the result page, choose the appropriate Hardware Compatibility List (HCL) for libraries or drives.</li> </ul> |                                  |                                  |                                  |                                  |        |
| <b>Operating System</b>   | <b>3580</b>                      | <b>TS2900</b>                    | <b>TS4300</b>                    | <b>TS3500/TS4500/Diamondback</b> |        |
|   | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | TS1150 |
| Windows   | •                                | •                                | •                                | •                                | •      |
| <b>Notes:</b>   |                                  |                                  |                                  |                                  |        |
| WORM support with LTO   |                                  |                                  |                                  |                                  |        |
| *Diamondback supports LTO9 and LTO10 only   |                                  |                                  |                                  |                                  |        |
| <b>Note on tape device drivers:</b>   |                                  |                                  |                                  |                                  |        |
| Libraries: Use the Symantec device driver.  |                                  |                                  |                                  |                                  |        |
| Drives: Use the Symantec device driver.   |                                  |                                  |                                  |                                  |        |

**THE INFORMATION IN THIS DOCUMENT IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY, OR COMPATIBILITY.**



**Acronis: Cyber Backup Advanced /Cyber Protect Advanced → [website](#)**

| Operating System | 3580                             | TS4300                           | TS3500/TS4500/Diamondback*       |
|------------------|----------------------------------|----------------------------------|----------------------------------|
|                  | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 |
| Windows          | •                                | •                                | •                                |

**Notes:** Diamondback supports LTO9 and LTO10 only

**Arcserve: Arcserve Backup → [website](#)**

| Operating System | 3580                             | TS2900                           | TS4300                           | TS3500/TS4500/Diamondback*       |                  |
|------------------|----------------------------------|----------------------------------|----------------------------------|----------------------------------|------------------|
|                  | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | TS1150<br>TS1160 |
| Linux            | •                                | •                                | •                                | •                                | •                |
| Windows          | •                                | •                                | •                                | •                                | •                |

**Notes:**

- Use native driver
- Diamondback supports LTO9 and LTO10 only

THE INFORMATION IN THIS DOCUMENT IS PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY, OR COMPATIBILITY.



**Atempo: Time Navigator & MIRIA** → [website](#)

**Notes on ISV site navigation:** On the website above, select “ATN Hardware Compatibility Guide” for a list of supported devices.

| Operating System | 3580                             | TS2900                           | TS4300                           | TS3500/TS4500/Diamondback*                 |                  |
|------------------|----------------------------------|----------------------------------|----------------------------------|--|------------------|
|                  | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9<br>LTO 10 | TS1150<br>TS1160 |
| Linux            | •                                | •                                | •                                | •  | •                |
| Mac OS           | •                                | •                                | •                                | •  | •                |
| Windows          | •                                | •                                | •                                | •  | •                |

**Notes:**

\*Diamondback supports LTO9 and LTO10 only

**On tape device drivers:**

Libraries: Check with Atempo for supported drivers (use either Atempo provided driver or SCSI pass-through driver.) Use of IBM device driver not supported.

Drives: Use the native operating system device driver with the following exceptions:

- On Windows, use the IBM tape driver available from <http://www-933.ibm.com/support/fixcentral/>
- On Mac OS, use Atempo’s tape device driver

IBM control path failover (CPF), data path failover (DPF) and system-managed encryption (SME) features require use of the IBM tape device drivers. DPF is supported on Windows. SME is supported on Windows.

**THE INFORMATION IN THIS DOCUMENT IS PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY, OR COMPATIBILITY.**



|  |                                    |
|--|------------------------------------|
| <b>Brandl Systemhaus: EfficientNodes -&gt; <a href="#">website</a></b> |                                    |
| <b>Operating System</b>  | <b>Deep Archive on Diamondback</b> |
|  | LTO 9 SAS<br>LTO 10 SAS            |
| Windows  | •                                  |
| Linux  | •                                  |

|  |                                  |                                  |                                  |  |                            |
|--|----------------------------------|----------------------------------|----------------------------------|--|----------------------------|
| <b>CommVault Systems: Commvault → <a href="#">website</a></b>  |                                  |                                  |                                  |  |                            |
| <b>Notes on ISV site navigation:</b>   |                                  |                                  |                                  |  |                            |
| <ul style="list-style-type: none"> <li>On the website above, select the “Lookup by Device Type” option.</li> <li>On the resulting page, select the “All Device Types”.</li> </ul> <p>On the following page, choose IBM as the hardware vendor.</p> |                                  |                                  |                                  |  |                            |
| <b>Operating System</b>  | <b>3580</b>                      | <b>TS2900</b>                    | <b>TS4300</b>                    | <b>TS3500/TS4500/Diamondback*</b>          |                            |
|  | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9<br>LTO 10 | TS1150<br>TS1160<br>TS1170 |
| AIX  | •                                | •                                | •                                | •  | •                          |
| Linux  | •                                | •                                | •                                | •  | •                          |
| Windows  | •                                | •                                | •                                | •  | •                          |
| <b>Notes:</b>  |                                  |                                  |                                  |  |                            |
| <ul style="list-style-type: none"> <li>WORM supported</li> <li>CommVault supports application-managed encryption (AME)</li> </ul>  |                                  |                                  |                                  |  |                            |
| <b>Notes:</b>  |                                  |                                  |                                  |  |                            |
| *Diamondback supports LTO9 and LTO10 only  |                                  |                                  |                                  |  |                            |
| <b>On tape device drivers</b>  |                                  |                                  |                                  |  |                            |
| Libraries: Use the SCSI pass-through driver on all operating systems with the following exceptions:  |                                  |                                  |                                  |  |                            |
| <ul style="list-style-type: none"> <li>On Windows, use the IBM tape driver from <a href="http://www-933.ibm.com/support/fixcentral/">http://www-933.ibm.com/support/fixcentral/</a></li> </ul>   |                                  |                                  |                                  |  |                            |
| Drives: Use the SCSI pass-through driver on all operating systems with the following exceptions:   |                                  |                                  |                                  |  |                            |
| <ul style="list-style-type: none"> <li>On Windows, use the IBM tape driver from <a href="http://www-933.ibm.com/support/fixcentral/">http://www-933.ibm.com/support/fixcentral/</a></li> </ul>   |                                  |                                  |                                  |  |                            |
| The SME feature requires the use of the IBM tape device drivers. SME is supported on Windows.  |                                  |                                  |                                  |  |                            |

**THE INFORMATION IN THIS DOCUMENT IS PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY, OR COMPATIBILITY.**



Cohesity: NetBackup → [website](#)

**Notes on ISV site navigation:**

On the website above, enter "NetBackup" in the Product Lookup box. Search the Knowledge Base for Hardware Compatibility List. Click the NetBackup version of interest.

| Operating System | 3580                             | TS2900                           | TS4300                           | TS3500/TS4500/Diamondback                  |                            |
|------------------|----------------------------------|----------------------------------|----------------------------------|--|----------------------------|
|                  | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9<br>LTO 10 | TS1150<br>TS1160<br>TS1170 |
| Linux            | •                                | •                                | •                                | •  | •                          |
| Windows          | •                                | •                                | •                                | •  | •                          |

**Notes:**

- WORM support with Ultrium3, Ultrium4, Ultrium5, Ultrium6, Ultrium7 and 3592 drives
- Support for library-based Internal Label Encryption Policy (ILEP) for 3592 E05 and LTO4
- TS4300(3573) Supports LTO6 drives and later only
- Diamondback supports LTO9 and LTO10 only

**On tape device drivers:** Check the Symantec Hardware Compatibility Lists located on the Symantec support website for the latest tested IBM driver levels.

Libraries: On AIX, install and configure the Symantec ovpass driver. On all other operating systems use the native device driver.

Drives:

- On AIX, use the IBM AIX Atape tape driver.
- On Windows, use the IBM tape drivers.
- On all other operating systems use the native operating system tape device driver.

IBM tape drivers can be downloaded from <http://www-933.ibm.com/support/fixcentral/>

The IBM SME feature requires use of the IBM tape device drivers. SME is supported on AIX and Windows.

**THE INFORMATION IN THIS DOCUMENT IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY, OR COMPATIBILITY.**



DELL/EMC: NetWorker → [website](#)

Notes on site navigation: At Dell NetWorker page at documents section search NetWorker Hardware Compatibility Guide

| Operating System | 3580                             | TS2900                           | TS4300                           | TS3500/TS4500/Diamond back*      |                            |
|------------------|----------------------------------|----------------------------------|----------------------------------|----------------------------------|----------------------------|
|                  | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | TS1150<br>TS1160<br>TS1170 |
| AIX              | •                                | •                                | •                                | •                                | •                          |
| Linux            | •                                | •                                | •                                | •                                | •                          |
| Windows          | •                                | •                                | •                                | •                                | •                          |

**Notes:**

NetWorker supports encryption as long as the key is managed by an original equipment manufacturer (OEM) vendor

\*Diamondback supports LTO9 and LTO10 only

**On tape device drivers:**

**Libraries:** Use the pass-through device driver

**Drives:**

On Windows, use IBM tape device driver only

On AIX, use IBM Atape device driver only

On Linux, use the native “st” driver only

IBM tape device drivers are available at <http://www-933.ibm.com/support/fixcentral/>

IBM path failover (CPF and DPF) and SME features require use of the IBM tape device drivers. DPF is supported on AIX [Fibre Channel (FC) only] and Windows. SME is supported on AIX and Windows

THE INFORMATION IN THIS DOCUMENT IS PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY, OR COMPATIBILITY.



| <b>EchleafSystems: Echleaf Systems Virtual Drive</b> → <a href="#">pdf</a>                |                                  |                                  |                                  |                  |
|---|----------------------------------|----------------------------------|----------------------------------|------------------|
| <b>Notes on Echleaf:</b> In the above link Echleaf publish the pdf with compliance matrix |                                  |                                  |                                  |                  |
| Operating System  | TS2900                           | TS4300                           | TS3500/TS4500                    |                  |
|   | LTO 5<br>LTO 6<br>LTO 7<br>LTO 8 | LTO 5<br>LTO 6<br>LTO 7<br>LTO 8 | LTO 5<br>LTO 6<br>LTO 7<br>LTO 8 | TS1150<br>TS1160 |
| Linux   | •                                | •                                | •                                | •                |
| <b>Notes:</b><br>On tape device drivers - Use IBM tape driver                             |                                  |                                  |                                  |                  |

| <b>IBM: Archive Drive Edition</b> → <a href="#">website</a>  |   |                            |
|--|---|----------------------------|
| <b>Notes on Navigation:</b> If above link broken go to fixcentral and find the SDE support matrix on the Storage Archive download list |   |                            |
| Operating System   | 3580                                      | 3592                       |
|  | LTO 5<br>LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | TS1150<br>TS1160<br>TS1170 |
| Linux  | •   | •                          |
| Mac OS   | •   | •                          |
| Windows  | •   | •                          |

THE INFORMATION IN THIS DOCUMENT IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY, OR COMPATIBILITY.



| <b>IBM: Archive Enterprise Edition</b> → <a href="#">website</a>  |                                  |   |                            |
|---|----------------------------------|---|----------------------------|
| <b>Notes on Navigation:</b> If above link broken go to fixcentral and find the EE support matrix on the Storage Archive download list |                                  |   |                            |
| Operating System  | TS4300                           | TS3500/TS4500/Diamondback*                          |                            |
|   | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 5<br>LTO 6<br>LTO 7<br>LTO 8<br>LTO 9<br>LTO 10 | TS1150<br>TS1160<br>TS1170 |
| Linux   | •                                | •   | •                          |
| <b>Notes:</b><br>*Diamondback supports LTO9 and LTO10 only  |                                  |   |                            |

| <b>IBM: Archive Library Edition</b> → <a href="#">website</a>   |   |                                  |   |                            |
|---|---|----------------------------------|---|----------------------------|
| <b>Notes on Navigation:</b> If above link broken go to fixcentral and find the LE support matrix on the Storage Archive download list |   |                                  |   |                            |
| Operating System  | TS2900                                    | TS4300                           | TS3500/TS4500/Diamondback*                          |                            |
|   | LTO 5<br>LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 5<br>LTO 6<br>LTO 7<br>LTO 8<br>LTO 9<br>LTO 10 | TS1150<br>TS1160<br>TS1170 |
| Linux   | •   | •                                | •   | •                          |
| Windows   | •   | •                                | •   | •                          |
| <b>Notes:</b><br>*Diamondback supports LTO9 and LTO10 only  |   |                                  |   |                            |

THE INFORMATION IN THIS DOCUMENT IS PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY, OR COMPATIBILITY.



|  |                             |
|--|-----------------------------|
| IBM: Archive and Essence Manager → <a href="#">website</a> |                             |
| Operating System   | Deep Archive on Diamondback |
|  | LTO 9 SAS<br>LTO 10 SAS     |
| Linux  | •                           |

|  |                             |
|--|-----------------------------|
| IBM Cloud Object Storage → <a href="#">website</a> |                             |
| Operating System                                   | Deep Archive on Diamondback |
|  | LTO 9 SAS<br>LTO 10 SAS     |
| Any ISV OS   | Future                      |

|  |                                  |                                  |  |                            |
|--|----------------------------------|----------------------------------|--|----------------------------|
| IBM: HPSS → <a href="#">website</a>  |                                  |                                  |  |                            |
| Operating System   | 3580                             | TS4300                           | TS3500/TS4500/Diamondback*                 |                            |
|  | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9<br>LTO 10 | TS1150<br>TS1160<br>TS1170 |
| AIX  | •                                | •                                | •  | •                          |
| Linux  | •                                | •                                | •  | •                          |
| <b>Notes:</b><br>For both AIX and Linux, use native device driver<br>*Diamondback supports LTO9 and LTO10 only |                                  |                                  |  |                            |

THE INFORMATION IN THIS DOCUMENT IS PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY, OR COMPATIBILITY.



| IBM RMS → <a href="#">website</a>                       |                                  |                                  |  |                            |
|---|----------------------------------|----------------------------------|--|----------------------------|
| Operating System  | 3580                             | TS4300                           | TS3500/TS4500/Diamondback*                 |                            |
|   | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9<br>LTO 10 | TS1150<br>TS1160<br>TS1170 |
| IBM i   | •                                | •                                | •  | •                          |
| <b>Notes:</b> *Diamondback supports LTO9 and LTO10 only |                                  |                                  |  |                            |

| IBM: IBM Guardium Key Lifecycle Manager → <a href="#">website</a>  |                                  |  |                            |
|--|----------------------------------|--|----------------------------|
| Operating System   | TS4300                           | TS3500/TS4500/Diamondback*                 |                            |
|  | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9<br>LTO 10 | TS1150<br>TS1160<br>TS1170 |
| All  | •                                | •  | •                          |
| <b>Notes:</b> <ul style="list-style-type: none"><li>▪ IBM SKLM for zOS does not support the TS4300 tape library</li><li>▪ IBM SKLM V2.7 does not support self-signed certificates with the TS4300 tape library</li></ul> |                                  |  |                            |

| IBM Storage Ceph → <a href="#">website</a>   |                             |
|--|-----------------------------|
| Operating System   | Deep Archive on Diamondback |
|  | LTO 9 SAS<br>LTO 10 SAS     |
| RHEL   | •                           |
| <b>Notes:</b> 1.1.0 or later. S3 Glacier API (validated with 3 million objects per bucket). <a href="#">Link</a> |                             |

THE INFORMATION IN THIS DOCUMENT IS PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY, OR COMPATIBILITY.



|   |                             |
|---|-----------------------------|
| IBM Storage Defender Data Protect → <a href="#">website</a> |                             |
| Operating System  | Deep Archive on Diamondback |
|   | LTO 9 SAS<br>LTO 10 SAS     |
| NA (appliance)  | •                           |
| <b>Note.-</b> Supported starting on 7.1.2_u3                |                             |

| IBM: Storage Protect → <a href="#">website</a>  |                                  |                                  |                                  |  |                            |                         |
|---|----------------------------------|----------------------------------|----------------------------------|--|----------------------------|-------------------------|
| Operating System  | 3580                             | TS2900                           | TS4300                           | TS3500/TS4500/Diamondback*                 | Deep Archive Diamondback   |                         |
|   | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9<br>LTO 10 | TS1150<br>TS1160<br>TS1170 | LTO 9 SAS<br>LTO 10 SAS |
| AIX   | •                                | •                                | •                                | •  | •                          | Future                  |
| Linux   | •                                | •                                | •                                | •  | •                          |                         |
| Windows   | •                                | •                                | •                                | •  | •                          |                         |
| <b>Notes:</b><br>*Diamondback supports LTO9 and LTO10 only<br>WORM support with 3592 (TS11) and 3580<br><b>On tape device drivers and software:</b><br>Libraries and Drives: Use the IBM device driver<br>IBM tape drivers can be downloaded from <a href="http://www-933.ibm.com/support/fixcentral/">http://www-933.ibm.com/support/fixcentral/</a> |                                  |                                  |                                  |  |                            |                         |

THE INFORMATION IN THIS DOCUMENT IS PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY, OR COMPATIBILITY.



|   |                             |
|---|-----------------------------|
| IBM Storage Scale AFM → <a href="#">website</a> |                             |
| Operating System                                | Deep Archive on Diamondback |
|   | LTO 9 SAS<br>LTO 10 SAS     |
| NA  | •                           |

|  |                             |
|--|-----------------------------|
| IBM Storage TS7700 → <a href="#">website</a> |                             |
| Operating System                             | Deep Archive on Diamondback |
|  | LTO 9 SAS<br>LTO 10 SAS     |
| NA (appliance)                               | •                           |
| <b>Notes:</b> Starting on TS7700 8.6         |                             |

|  |                         |                         |                         |                         |
|--|-------------------------|-------------------------|-------------------------|-------------------------|
| Microsoft System Center Data Protection Manager → <a href="#">website</a>  |                         |                         |                         |                         |
| Operating System   | 3580                    | TS2900                  | TS4300                  | TS3500/TS4500           |
|  | LTO 6<br>LTO 7<br>LTO 8 | LTO 6<br>LTO 7<br>LTO 8 | LTO 6<br>LTO 7<br>LTO 8 | LTO 6<br>LTO 7<br>LTO 8 |
| Windows  | •                       | •                       | •                       | •                       |
| <b>Notes:</b><br><b>On tape device drivers:</b><br>IBMTape Device Driver required with non-exclusive installation so no CPF or DPF support |                         |                         |                         |                         |

THE INFORMATION IN THIS DOCUMENT IS PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY, OR COMPATIBILITY.



| NetApp: NetApp Data Storage → <a href="#">website</a>     |                                  |        |
|---|----------------------------------|--------|
| Operating System  | 3580                             | 3592   |
|   | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | TS1150 |
| NETAPP OS   | •                                | •      |
| <b>Notes:</b><br>NetApp Qualification is for drives only. |                                  |        |

| OpenText: Data Protector → <a href="#">website</a>  |                                  |                                  |                                  |                                  |
|---|----------------------------------|----------------------------------|----------------------------------|----------------------------------|
| Operating System  | 3580                             | TS2900                           | TS4300                           | TS3500/TS4500/Diamondback*       |
|   | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 |
| Linux   | •                                | •                                | •                                | •                                |
| Windows   | •                                | •                                | •                                | •                                |
| <b>Notes:</b><br>*Diamondback supports LTO9 and LTO10 only  |                                  |                                  |                                  |                                  |
| <b>On tape device drivers</b>   |                                  |                                  |                                  |                                  |
| <ul style="list-style-type: none"> <li>To utilize IBM 3584 on Linux, the IBM device drivers are required. These can be obtained from the following web page: <a href="https://www.ibm.com/support/fixcentral">https://www.ibm.com/support/fixcentral</a></li> <li>IBM path failover (CPF and DPF) and SME features require use of the IBM tape device drivers.</li> </ul> |                                  |                                  |                                  |                                  |
| <b>Notes:</b>   |                                  |                                  |                                  |                                  |

THE INFORMATION IN THIS DOCUMENT IS PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY, OR COMPATIBILITY.



| Oracle: SAM-QFS - HSM → <a href="#">website</a> |             |                            |        |
|---|-------------|----------------------------|--------|
| Operating System                                | 3580        | TS3500/TS4500/Diamondback* |        |
|   | LTO 6,7,8,9 | LTO 6,7,8,9                | TS1150 |
| Solaris   | •           | •                          | •      |

**Notes:** \*Diamondback supports LTO9 and LTO10 only

| Oracle: OSB → <a href="#">website</a> |             |                            |        |
|---------------------------------------|-------------|----------------------------|--------|
| Operating System                      | TS4300      | TS3500/TS4500/Diamondback* |        |
|                                       | LTO 6,7,8,9 | LTO 6,7,8,9                | TS1150 |
| Linux                                 | •           | •                          | •      |
| Windows                               | •           | •                          | •      |

**Notes:** \*Diamondback supports LTO9 and LTO10 only

| Panzura: Symphony → <a href="#">website</a> |                             |
|---|-----------------------------|
| Operating System                            | Deep Archive on Diamondback |
|   | LTO 9 SAS<br>LTO 10 SAS     |
| RHEL  | •                           |
| Ubuntu                                      | •                           |
| Windows                                     | •                           |

THE INFORMATION IN THIS DOCUMENT IS PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY, OR COMPATIBILITY.



Point: PoINT Archival Gateway → [website](#)

| Operating System | TS4300                           | TS3500/TS4500/Diamondback*                 |                            |
|------------------|----------------------------------|--|----------------------------|
|                  | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9<br>LTO 10 | TS1150<br>TS1160<br>TS1170 |
| Windows          | •                                | •  | •                          |
| Linux            | •                                | •  | •                          |

**Notes:**  
 \*Diamondback supports LTO9 and LTO10 only  
**On tape device drivers:**  
 Libraries: PoINT Archival Gateway uses native drivers.  
 Drives: PoINT Archival Gateway uses native drivers.

Qstar → [website](#)

| Operating System | 3580                             | TS2900                           | TS4300                           | TS3500/TS4500/Diamondback*                 |                                      |
|------------------|----------------------------------|----------------------------------|----------------------------------|--|--------------------------------------|
|                  | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9<br>LTO 10 | TS1140<br>TS1150<br>TS1160<br>TS1170 |
| Linux            | •                                | •                                | •                                | •  | •                                    |
| Windows          | •                                | •                                | •                                | •  | •                                    |

**Notes:** \*Diamondback supports LTO9 and LTO10 only

THE INFORMATION IN THIS DOCUMENT IS PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY, OR COMPATIBILITY.



| <b>Quest Software: NetVault</b> → <a href="#">website</a>   |                                  |                                  |                                  |  |                            |
|---|----------------------------------|----------------------------------|----------------------------------|--|----------------------------|
| <b>Notes on ISV site navigation:</b> On the website above, select “NetVault Backup Compatibility List: Supported VTLs, Libraries, Tape Drives” under “Docs”   |                                  |                                  |                                  |  |                            |
| Operating System  | 3580                             | TS2900                           | TS4300                           | TS3500/TS4500/Diamondback                  |                            |
|   | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9 | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9<br>LTO 10 | TS1150<br>TS1160<br>TS1170 |
| AIX   | •                                | •                                | •                                | •  | •                          |
| Linux   | •                                | •                                | •                                | •  | •                          |
| Windows   | •                                | •                                | •                                | •  | •                          |
| <b>Notes:</b><br>TS4300 (3573) Supports LTO6 drives and later only<br>Diamondback supports LTO9 and LTO10 only<br><b>On tape device drivers:</b><br>Libraries: Use SCSI pass-through driver<br>Drives: Use SCSI pass-through driver |                                  |                                  |                                  |  |                            |

| <b>Saurabhi Media: Archive Mediator</b> → <a href="#">website</a> |                             |
|---|-----------------------------|
| Operating System  | Deep Archive on Diamondback |
|   | LTO 9 SAS<br>LTO 10 SAS     |
| Windows   | •                           |

THE INFORMATION IN THIS DOCUMENT IS PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY, OR COMPATIBILITY.



| SEP: Sesam → <a href="#">website</a>                      |                                   |                                   |                                   |                                   |        |
|---|-----------------------------------|-----------------------------------|-----------------------------------|-----------------------------------|--------|
| Operating System  | 3580                              | TS2900                            | TS4300                            | TS3500/TS4500/Diamondback*        |        |
|   | LTO 7<br>LTO 8<br>LTO 9<br>LTO 10 | LTO 7<br>LTO 8<br>LTO 9<br>LTO 10 | LTO 7<br>LTO 8<br>LTO 9<br>LTO 10 | LTO 7<br>LTO 8<br>LTO 9<br>LTO 10 | TS1170 |
| Windows   | •                                 | •                                 | •                                 | •                                 | •      |
| Linux   | •                                 | •                                 | •                                 | •                                 | •      |
| <b>Notes:</b><br>Sesam requires IBMTape driver in Windows |                                   |                                   |                                   |                                   |        |

| Starfish Storage: Starfish → <a href="#">website</a> |                             |
|--|-----------------------------|
| Operating System                                     | Deep Archive on Diamondback |
|  | LTO 9 SAS<br>LTO 10 SAS     |
| Linux  | •                           |
| Windows  | •                           |

THE INFORMATION IN THIS DOCUMENT IS PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY, OR COMPATIBILITY.



| Telestream : DIVA → <a href="#">website</a> |             |                            |             |                             |
|---|-------------|----------------------------|-------------|-----------------------------|
| Operating System                            | TS4300      | TS3500/TS4500/Diamondback* |             | Deep Archive on Diamondback |
|   | LTO 6,7,8,9 | LTO 6,7,8,9                | LTO 6,7,8,9 | LTO 9 SAS<br>LTO 10 SAS     |
| Linux                                       | •           | •                          | •           | •                           |
| Windows                                     | •           | •                          | •           | •                           |

**Notes:** \*Diamondback supports LTO9 and LTO10 only

| Veeam: Veeam Backup and Replication → <a href="#">website</a> |                         |                         |                         |                                   |          |
|---|-------------------------|-------------------------|-------------------------|-----------------------------------|----------|
| Operating System  | 3580                    | TS2900                  | TS4300                  | TS3500/TS4500/Diamondback*        |          |
|   | LTO 7<br>LTO 8<br>LTO 9 | LTO 7<br>LTO 8<br>LTO 9 | LTO 7<br>LTO 8<br>LTO 9 | LTO 7<br>LTO 8<br>LTO 9<br>LTO 10 | TS1170** |
| Windows   | •                       | •                       | •                       | •                                 | •        |
| Linux   | •                       | •                       | •                       | •                                 | •        |

**Notes:**  
 Veeam requires IBMTape driver  
 Supports: ALMS, failover, LTO transparent encryption, full capacity  
 \*Diamondback supports LTO9 and LTO10 only  
 \*\* All 3592 Compatibility

THE INFORMATION IN THIS DOCUMENT IS PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY, OR COMPATIBILITY.



| <b>Verity: VSM (Verity Storage Manager) → <a href="#">website</a></b> |  |                            |
|---|--|----------------------------|
| Operating System  | TS3500/TS4500/Diamondback*                 |                            |
|   | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9<br>LTO 10 | TS1150<br>TS1160<br>TS1170 |
| Linux   | •  | •                          |
| <b>Notes:</b><br>*Diamondback supports LTO9 and LTO10 only            |  |                            |

| <b>Verity: ScoutAM (Scale Out Archive Manager) → <a href="#">website</a></b> |  |                            |
|--|--|----------------------------|
| Operating System   | TS3500/TS4500/Diamondback*                 |                            |
|  | LTO 6<br>LTO 7<br>LTO 8<br>LTO 9<br>LTO 10 | TS1150<br>TS1160<br>TS1170 |
| Linux  | •  | •                          |
| <b>Notes:</b><br>*Diamondback supports LTO9 and LTO10 only                   |  |                            |

THE INFORMATION IN THIS DOCUMENT IS PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, INTEROPERABILITY, OR COMPATIBILITY.